


	Item	Description	Order no.	Qty. per pattern											
				321	330	431	541	550	532	651	633	761	770	743	
F&S basic hardware set K-18391-00-0 up to 80kg	1	F&S bogie	6-35981-00-0												
	2	F&S guide roll	6-36053-00-0												
	3	F&S pivot-rest	6-36114-00-L 6-36114-00-R	1	1	1	2	2	2	2	3	3	3		
	4	F&S plate	9-47147-00-0												
	5	Countersunk screw DIN 7500 – ME M4 x 16 – 8.8-H	9-13785-16-R												
F&S sash hinge set K-18394-50-0	6	F&S sash hinge complete	6-36113-50-0	1	2	2	3	4	3	4	4	5	6	5	
F&S PVC profiles set K-18395-99-0	7	F&S roller track	2960	9-47431-30-0											
			3960	9-47431-40-0											
			5000	9-47431-50-0											
			6700	9-47431-67-0											
	8	F&S guide track	2960	9-47432-30-0											
			3960	9-47432-40-0											
			5000	9-47432-50-0											
			6700	9-47432-67-0											
	9	F&S cover profile for roller track	2960	P-01953-30-0											
			3960	P-01953-40-0											
			5000	P-01953-50-0											
			6700	P-01953-67-0											
	10	F&S cover profile for guide track	2960	P-01954-30-0	1										
3960			P-01954-40-0												
5000			P-01954-50-0												
6700			P-01954-67-0												
11	F&S brush seal	2960	9-47560-30-0												
		3960	9-47560-40-0												
		5000	9-47560-50-0												
		6700	9-47560-67-0												
12	F&S end cap for roller track		9-47564-01-L 9-47564-01-R												
13	F&S end cap for guide track		9-47563-01-L 9-47563-01-R												
15	Corner-drive	6-32021-00-0	2	1	2	2	1	2	2	2	2	1	2		
F&S adapter set for roller track PVC K-18398-00-0	7A	F&S roller track	9-47431-11-0	1											
	31	F&S cover cap	6-37083-00-0												
CLS-LOG	21A	ZH FHH lever-operated gear (fixed handle height)	SRH 851-1100	G-22182-00-0	1	-	1	1	-	1	1	1	1	-	1
			SRH 1101-1350	G-22183-00-0											
			SRH 1351-1600	G-22184-00-0											
			SRH 1601-1850	G-22185-00-0											
			SRH 1851-2100	G-22186-00-0											
21B	ZH VHH lever-operated gear (variable handle height)	SRH 2101-2350	G-22187-00-0	1	-	1	1	-	1	1	1	1	-	1	
		SRH 851-950	G-22170-00-0												
		SRH 951-1450	G-22171-00-0												
26	DIRIGENT-F/F turn handle	SRH 1451-1950	G-22172-00-0	1	2	2	3	4	3	4	4	5	6	5	
		SRH 1951-2350	G-22173-00-0												
			6-28101-99-0												
26A	DIRIGENT-F turn handle	6-28072-99-0	1												
F&S strikers set K-18985-99	28A	F&S striker	acc. to profile	Number of strikers depending on element size											
	28B	Standard striker													
	28G	Steel Sec striker													
F&S drilling jig set for pivot-rest K-18870-99-0	29	Drilling jig set for pivot-rest	acc. to profile												
F&S drilling jig set for sash hinge complete K-18875-99-0	30	Drilling jig set for complete sash hinge	acc. to profile												
CLS-w/LC-MA15 CLS-T&T	50A	FHH gear, 15 BS	SRH 851-1100	1	G-22124-00-0	1	1	1	1	1	1	1	1	1	1
			SRH 1101-1350	1	G-22125-00-0										
50D	VHH gear, 15 BS	SRH 1351-1600	2	G-22127-00-0	1	1	1	1	1	1	1	1	1	1	1
		SRH 1601-1850	3	G-22128-00-0											
50E	FHH gear, 15 BS, without locking cam	SRH 1851-2100	3	G-22133-00-0	1	1	1	1	1	1	1	1	1	1	1
		SRH 2101-2350	4	G-22134-00-0											
50F	VHH gear, 15 BS, without locking cam	SRH 851-1200	1	G-22082-00-0	1	1	1	1	1	1	1	1	1	1	1
		SRH 951-1450	1	G-22083-00-0											
50G	VHH gear, 15 BS, without locking cam	SRH 1201-1700	2	G-22084-00-0	1	1	1	1	1	1	1	1	1	1	1
		SRH 1451-1950	2	G-22085-00-0											
50H	VHH gear, 15 BS, without locking cam	SRH 1951-2350	3	G-22086-00-0	1	1	1	1	1	1	1	1	1	1	1
		SRH 851-1100	0	G-22401-00-0											
50I	FHH gear, 15 BS, without locking cam	SRH 1101-1350	0	G-22402-00-0	1	1	1	1	1	1	1	1	1	1	1
		SRH 1351-1600	0	G-22404-00-0											
50J	FHH gear, 15 BS, without locking cam	SRH 1601-1850	0	G-22405-00-0	1	1	1	1	1	1	1	1	1	1	1
		SRH 1851-2100	0	G-22410-00-0											
50K	VHH gear, 15 BS, without locking cam	SRH 2101-2350	0	G-22411-00-0	1	1	1	1	1	1	1	1	1	1	1
		SRH 851-1200	0	G-22800-00-0											
50L	VHH gear, 15 BS, without locking cam	SRH 951-1450	0	G-22801-00-0	1	1	1	1	1	1	1	1	1	1	1
		SRH 1201-1700	0	G-22802-00-0											
50M	VHH gear, 15 BS, without locking cam	SRH 1451-1950	0	G-22803-00-0	1	1	1	1	1	1	1	1	1	1	1
		SRH 1951-2350	0	G-22804-00-0											


	Item	Description	Order no.	Qty. per pattern											
				321	330	431	541	550	532	651	633	761	770	743	
				V/	W	V/	W/	W	V	W	V	W	W	W	
CLS-w/oLC-MA45	50G	FHH gear, 45 BS, without locking cam	SRH 851-1100	0	6-33212-45-0										
			SRH 1101-1350	0	6-33213-45-0										
			SRH 1351-1600	0	6-33214-45-0										
			SRH 1601-1850	0	6-33215-45-0										
			SRH 1851-2100	0	6-33216-45-0										
			SRH 2101-2350	0	6-33217-45-0										
	50H	VHH gear, 45 BS, without locking cam	SRH 851-950	0	G-22343-45-0										
			SRH 951-1450	0	6-38945-45-0										
			SRH 1451-1950	0	6-39027-45-0										
			SRH 1951-2350	0	6-39028-45-0										
	51	Extension piece 90°		6-32624-00-0	1	2	2	3	4	3	4	4	5	6	5
	51A	Extension piece 180° (VHH)		6-32303-00-0	3	3	4	5	5	5	6	6	7	7	7
	51B	Gear connector 90° with LC-MA		6-32104-00-0	-	1	-	-	1	1	-	1	-	1	1
52	Sec centre-lock	SRH 851-1100	2	6-32008-05-0											
		SRH 1101-1350	2	6-32008-07-0											
		SRH 1351-1850	3	6-32008-12-0	2	1	2	2	2	2	2	1	2		
		SRH 1851-2100	3	6-32008-15-0											
		SRH 2101-2350	4	6-32008-19-0											
52B	T&T centre-lock (FHH + VHH)	SRW 751-1000	2	6-32076-05-0											
52C	Sec centre-lock 215 (FHH + VHH)	SRW 500-750	1	6-32012-00-0	2	1	2	2	1	2	2	2	1	2	
52D	Sec centre-lock 215-C		1	6-32011-00-0	2	4	4	6	8	6	8	8	10	12	10
52L	Extension (horizontal top)	SRW 500-600	1	G-22385-03-0	2	4	4	6	8	6	8	8	10	12	10
		SRW 601-750	2	G-22385-06-0											
		SRW 751-1000	2	G-22385-08-0											
53	F&S packers set	3 mm		K-18510-03-0	acc. to profile										
		4 mm		K-18510-04-0											
		5 mm		K-18510-05-0											
		6 mm		K-18510-06-0											
		12 mm		K-18510-12-0											
	54	F&S spacing bushes set	42 mm		K-18986-42-0	acc. to profile									
			72 mm		K-18986-72-0										
			74 mm		K-18986-74-0										
			81 mm		K-18986-81-0										
			88 mm		K-18986-88-0										
		92 mm		K-18986-92-0											
56B	Folding catch		K-18929-10-0	-	1	1	-	1	1	1	2	-	1	1	
66	Travel restrictor 90° (FHH + VHH)		9-33432-00-0	1	1	1	1	1	2	1	2	1	1	2	
67	Rod guide (FHH)			5	4	6	7	6	7	8	8	9	8	9	
	Rod guide (VHH)		8-00805-00-0	7	5	8	9	7	9	10	10	11	9	11	
up to 80kg	68	UNI-JET D stay-guide	SRW 500-750	6-31512-06-0	2	1	2	2	1	2	2	2	1	2	
		SRW 751-1000		6-31512-08-0											
		UNI-JET SC stay-guide	SRW 500-750	1											6-34088-06-0
		SRW 751-1000	2	6-34088-08-0											
up to 80kg	TU-ON UNI-JET SC		Hinge-side	0-44889-DD-0	1	1	1	1	1	2	1	2	1	1	2
	T&T UNI-JET SC		Hinge-side	0-44889-DD-0	1	-	1	1	-	-	1	-	1	-	-
	TU-ON UNI-JET D		Hinge-side	0-46603-DD-0	1	1	1	1	1	2	1	2	1	1	2
	T&T UNI-JET D		Hinge-side	0-46603-DD-0	1	-	1	1	-	-	1	-	1	-	-
Accessories															
47	Drilling jig for roller track and guide track			6-37513-99-0											
44	DIRIGENT-F/A turn handle (exterior)			6-25993-99-0											
50B	PC gear 25 BS, FHH – PC gear 50 BS, FHH (lockable)			SRH 1851-2100	3	G-22315-99-0									
				SRH 2101-2350	4	G-22316-99-0									
55A	Installation aid for strikers			9-49291-00-0											
55B	Installation aid for bottom strikers			9-49290-99-0	1										
57	Drilling jig for folding catch			6-25575-00-0											
58	Open-end spanner SW17			9-48667-00-0											
59	UNI-JET adjusting tool			6-37291-00-0											
69	Pull-handle for stay-bearing pin			6-38513-99-0											

Pattern 431





Position of pivot-rests

Installation at the top
Standard installation / Alternative installation



Adapting the sash overlap in the area of the bogie (alternative version)









* = Dimension B only applies to patterns 321, 541, 532, 761 and 743.

! = With installation dimension 18 it is necessary to round off the overlap in the area of the F&S pivot-rest.

Note:
If the handle height (HH) coincides with the position of the centre hinges, all centre hinges should be displaced 100 mm upwards.

Position of hinges












Outside Inside



Place pressure-resistant supports under the roller track along its entire length.

Consider (+/-) signs when employing the a, b, c, d, e value in the formula.

g = laterally reversed



Pattern 431; Calculation example:: FRW = 3000; Coverage = 8; SG F&S = 3; SG TU-ON = 3; L = 35

$$B\ 1 = \frac{3000}{4} + 2,25 + (1 \times 8) + (-0,17 \times 3) + (-0,08 \times 3) + (0,5 \times 35) = 777$$


$$B = \frac{FRW}{\text{Number of leaves}} + a + (b \times \text{Coverage}) + (c \times \text{SG F\&S}) + (d \times \text{SG TU-ON}) + (e \times l)$$

Sectional views

Pattern	B 1	B 2	B 3	B 4	B 5	B 6	B 7
321	D-A a=1,50 b=1,00 c=-0,08 d=-0,08 e=0,67	A-B a=-3,00 b=0,00 c=-0,83 d=-0,83 e=-1,33	B-Dg a=1,50 b=1,00 c=-0,08 d=-0,08 e=0,67				
330	D-A a=3,00 b=1,33 c=-0,08 d=0,00 e=0,67	A-E a=-1,50 b=0,33 c=-1,50 d=0,00 e=-1,33	E-G a=-1,50 b=0,33 c=-0,50 d=0,00 e=0,67				
431	D-A a=2,25 b=1,00 c=-0,17 d=-0,08 e=0,50	A-E a=-2,25 b=0,00 c=-0,50 d=-0,25 e=-1,50	E-C a=-2,25 b=0,00 c=-0,50 d=-0,25 e=0,50	C-Dg a=2,25 b=1,00 c=-0,17 d=-0,08 e=0,50			
541	D-A a=2,70 b=1,00 c=-0,08 d=-0,03 e=0,80	A-E a=-1,80 b=0,00 c=-1,20 d=-0,40 e=-1,20	E-A a=-1,80 b=0,00 c=-0,45 d=-0,15 e=0,80	A-B a=-1,80 b=0,20 c=-1,20 d=-0,40 e=-1,20	B-Dg a=2,70 b=1,00 c=-0,08 d=-0,03 e=0,80		
550	D-A a=3,60 b=1,20 c=0,00 d=0,00 e=0,80	A-E a=-0,90 b=0,20 c=-1,50 d=0,00 e=-1,20	E-A a=-0,90 b=0,20 c=-0,50 d=0,00 e=0,80	A-E a=-0,90 b=0,20 c=-1,50 d=-0,03 e=0,80	E-G a=-0,90 b=0,20 c=-0,50 d=-0,03 e=0,80		
532	D-A a=2,70 b=1,00 c=-0,08 d=-0,03 e=0,80	A-E a=-1,80 b=0,00 c=-1,20 d=-0,15 e=-1,20	E-Bg a=-1,80 b=0,00 c=-0,45 d=-0,15 e=0,80	Bg-Ag a=-1,80 b=0,00 c=-1,20 d=-0,15 e=-1,20	Ag-Dg a=2,70 b=1,00 c=-0,08 d=-0,03 e=0,80		
651	D-A a=3,00 b=1,00 c=-0,13 d=-0,03 e=0,67	A-E a=-1,50 b=0,00 c=-1,33 d=-0,33 e=-1,33	E-A a=-1,50 b=0,00 c=-0,53 d=-0,13 e=0,67	A-E a=-1,50 b=0,00 c=-0,53 d=-0,13 e=-1,33	E-C a=-1,50 b=0,00 c=-0,53 d=-0,13 e=0,67	C-Dg a=3,00 b=1,00 c=-0,13 d=-0,03 e=0,67	
633	D-A a=3,00 b=1,00 c=-0,13 d=-0,03 e=0,67	A-E a=-1,50 b=0,00 c=-1,33 d=-0,33 e=-1,33	E-A a=-1,50 b=0,00 c=-0,53 d=-0,13 e=0,67	C-Eg a=-1,50 b=0,00 c=-0,53 d=-0,13 e=0,67	Eg-Ag a=-1,50 b=0,00 c=-1,33 d=-0,33 e=-1,33	Ag-Dg a=3,00 b=1,00 c=-0,13 d=-0,03 e=0,67	
761	D-A a=3,21 b=1,00 c=-0,06 d=-0,01 e=0,86	A-E a=-1,29 b=0,00 c=-1,31 d=-0,26 e=-1,14	E-A a=-1,29 b=0,00 c=-0,48 d=-0,10 e=0,86	A-E a=-1,29 b=0,00 c=-1,31 d=-0,26 e=-1,14	E-A a=-1,29 b=0,00 c=-0,48 d=-0,10 e=0,86	A-B a=-1,29 b=0,00 c=-1,31 d=-0,26 e=-1,14	B-Dg a=3,21 b=1,00 c=-0,06 d=-0,01 e=0,86
770	D-A a=3,86 b=1,14 c=0,00 d=0,00 e=0,86	A-E a=-0,64 b=0,14 c=-1,50 d=0,00 e=-1,14	E-A a=-0,64 b=0,14 c=-0,50 d=0,00 e=0,86	A-E a=-0,64 b=0,14 c=-1,50 d=0,00 e=-1,14	E-A a=-0,64 b=0,14 c=-0,50 d=0,00 e=-1,14	A-E a=-0,64 b=0,14 c=-1,50 d=0,00 e=-1,14	E-G a=-0,64 b=0,14 c=-0,50 d=0,00 e=0,86
743	D-A a=3,21 b=1,00 c=-0,06 d=-0,01 e=0,86	A-E a=-1,29 b=0,00 c=-1,31 d=-0,26 e=-1,14	E-A a=-1,29 b=0,00 c=-0,48 d=-0,10 e=0,86	A-B a=-1,29 b=0,00 c=-1,31 d=-0,26 e=-1,14	B-Eg a=-1,29 b=0,00 c=-0,48 d=-0,10 e=0,86	Eg-Ag a=-1,29 b=0,00 c=-1,31 d=-0,26 e=-1,14	Ag-Dg a=3,21 b=1,00 c=-0,06 d=-0,01 e=0,86


Note:
DIRIGENT-F turn handle
(6-28072-99) to be installed
on the passage sash.

Pattern 330 / 550 / 770



**Pattern 321 / 541 / 743 / 761
Pattern 532: mirrored view**

The top and bottom end cap of the dummy mullion profile must be rounded.



** Calculation of sash rebate width: SRW = calculated dimension B - 2 x overlap width

Attention!

The calculation formulas apply only if shadow gap (SG) and clearance (CL) are identical on all sashes.

With the pivot-rests it is necessary to mitre the reinforcement (top and bottom).


In this drawing calculation dimension (W) equals the sash width (SW).

**Sectional drawing
UNI-JET D up to 80 kg
sash weight**


Description
Fold&Slide hardware GU-923, inward
Neutral PVC profiles
Version with dummy-mullion profile




Release No.	Level	Released	Scale	Modification	Size
Ver	---	---	---	6	1
Draft		23.03.2017	Mj		
Replacement for ---				Drawing No. 0-46888-BM-0-EN	Sheet 3/14



Fixing the pivot-rest cover





Fixing / removing the sash-hinge cover







For attachment / removal of sash-hinge covers, the setscrews on the back must be tightened / loosened. Open sashes to access the screws, if the F&S unit is already installed.


Installation position of F&S plate (Item4)



F&S packer item 53 and F&S spacing bush item 54 must be attached to each hinge.




Vertical adjustment on guide roll / pivot-rest



Loosening and adjusting

- Hold the set bolt using an Allen key size 4.
 - Loosen and hold the locknut using an open-end spanner size 17.
 - Adjust vertically with Allen key size 4.
- #### Locking
- Hold the set bolt using an Allen key size 4.
 - Firmly tighten locknut with open-end spanner size 17.




Vertical adjustment on bogie / pivot-rest




Loosening and adjusting

- Hold the set bolt using an Allen key size 4.
 - Loosen and hold the locknut using an open-end spanner size 17.
 - Adjust vertically with Allen key size 4.
- #### Locking
- Hold the set bolt using an Allen key size 4.
 - Firmly tighten locknut with open-end spanner size 17.

Hinge adjustment



Note: After installation of all 3 hinges pull out pin for transport.




General overview of Fold&Slide hardware


Description					
Fold&Slide hardware GU-923, inward					
Neutral PVC profiles					
Version with dummy-mullion profile					
GU	Release No.	Level	Released	Scale	Modification
	Mod. No.	Ver.	23.03.2017	---	6
	Drawing No.	Draft	Mj		
Replacement for ---				0-46888-BM-0-EN	
					Sheet 4/14

Central locking system with BS15 gear without LC-MA
CLS-w/oLC-MA15



Central locking system with BS45 gear without LC-MA
CLS-w/oLC-MA45





When cropping the faceplate by less than 150 mm or when the notches are still visible after cropping, rod guide 8-00805 should be positioned at least 65 mm from the faceplate end.



Milling the sash
profile for fixing
the handle



Central locking system with BS15 gear with LC-MA
CLS-wLC-MA15





Lubricate all locking, moving, and bearing points with a lubricant free of resin and acid.

Description

Fold&Slide hardware GU-923, inward
Neutral PVC profiles
Version with dummy-mullion profile

	Release No. ---	Level	Released		Scale ---	Modification 6	Size 1
	Mod. No. G33134	Ver	---	---			
	Draft	23.03.2017	Mj				
	Replacement for ---					Drawing No. 0-46888-BM-0-EN	Sheet 5/14




Lubricate all locking, moving, and bearing points with a lubricant free of resin and acid.

CLS with
lever-operated gear

Description

Fold&Slide hardware GU-923, inward
Neutral PVC profiles
Version with dummy-mullion profile


	Release No.	Level	Released		Scale	Modification	Size
	Mod. No. G33134	Ver. --	---		---	6	1
		Draft	23.03.2017	Mj			Sheet
	Replacement for ---						
0-46888-BM-0-EN						6/14	



EN
ES
FR
RU
--

V5

Central locking system for Tilt&Turn windows CLS-T&T




**TU-ON central locking system /
T&T central locking system**


Description
Fold&Slide hardware GU-923, inward
Neutral PVC profiles
Version with dummy-mullion profile

	Release No. ---	Level	Released		Scale	Modification	Size
	Mod. No. G33134	Ver	--	--	---	6	1
		Draft	23.03.2017	Mj			
		Replacement for ---					
Drawing No. 0-46888-BM-0-EN						Sheet 7/14	

Pattern 321




Position of strikers




Using the striker installation aid



Strikers are mounted after the F&S unit is completely installed.



Pattern 330



Position of strikers



- F&S hinge
- Pivot-rest
- Folding catch

! = With installation dimension 18 it is necessary to round off the overlap in the area of the F&S pivot-rest.

Locking positions
for pattern
321 / 330

Description

Fold&Slide hardware GU-923, inward

Neutral PVC profiles


Version with dummy-mullion profile

GU	Release No.	Level	Released		Scale	Modification	Size
	--				--	6	1
	Mod. No.	Ver.	--	--			
	G33134						
		Draft	23.03.2017	Mj			
	Replacement by --						
						Drawing No.	Sheet
						0-46888-BM-0-EN	8/14


Description					
Fold&Slide hardware GU-923, inward					
Neutral PVC profiles					
Version with dummy-mullion profile					
	Released No.	Level	Released		Scale
	--		--	--	--
	Mod. No.	Val.			
	G33334	Draft	23.03.2017	Mj	
Replacement for --					Modification
					6
					Sheet
					9/14
					Drawing No.
					0-46888-BM-0-EN

Description						
Fold&Slide hardware GU-923, inward Neutral PVC profiles Version with dummy-mullion profile						
	Release No.	Level	Released		Scale	Modification
	---	Ver.	--	---	---	6
	Mod. No. G333134	Draft	23.03.2017	Mj		
Replacement for ---					Drawing No.	Sheet
					0-46888-BM-0-EN	10/14

Pattern 633




Position of strikers




Using the striker installation aid

Strikers are mounted after the F&S unit is completely installed.





1. Place installation aid on locking cam.
2. Close the sash.
3. Apply marking on frame.
4. Align striker with mark.
(Mind the locking direction.)

Pattern 651



Position of strikers



1. Place installation aid on locking cam.
2. Close the sash.
3. Apply marking on frame.
4. Align striker with mark.
(Mind the locking direction.)

- F&S hinge
- Pivot-rest
- Folding catch

! = With installation dimension 18 it is necessary to round off the overlap in the area of the F&S pivot-rest.


Locking positions
for pattern
633 / 651

Description


Fold&Slide hardware GU-923, inward
Neutral PVC profiles
Version with dummy-mullion profile

	Release No. --	Level ---	Released ---		Scale ---	Modification 6	Size 1	
	Mod. No. G33134	Ver. ---	Date 23.03.2017		Mj Mj	Drawing No. 0-46888-BM-0-EN	Sheet 11/14	
	Replacement by --							


Pattern 743




Position of strikers




Pattern 761




Position of strikers



Pattern 770




Position of strikers




Using the striker installation aid

Strikers are mounted after the F&S unit is completely installed.



1. Place installation aid on locking cam.
2. Close the sash.
3. Apply marking on frame.
4. Align striker with mark.
(Mind the locking direction.)





1. Place installation aid on locking cam.
2. Close the sash.
3. Apply marking on frame.
4. Align striker with mark.
(Mind the locking direction.)

- F&S hinge
- Pivot-rest
- Folding catch

! = With installation dimension 18 it is necessary to round off the overlap in the area of the F&S pivot-rest.

Locking positions
for pattern
743 / 770 / 761

Description Fold&Slide hardware GU-923, inward Neutral PVC profiles Version with dummy-mullion profile						
	Release No. ---	Level ---	Released ---		Scale ---	Size 1
	Mod. No. G33134	Ver. ---	Date 23.03.2017		Modifikation ---	Sheet 12/14
	Replacement by ---		Drawing No. 0-46888-BM-0-EN			





Operating sequence example: Fold&Slide unit
pattern 330 with folding catch

Opening:

- 1.) Release locking systems of all sashes via turn handle.
- 2.) Turn the Turn-Only sash by 180° so that the holder snaps into the folding catch.
- 3.) Now all sashes can be opened.

Closing:


- 4.) Move all sashes in their closed position.
- 5.) Release the Turn-Only sash while holding the folding sashes in their closed position.
- 6.) Lock all sashes via turn handle.




Folding catch

Description						
Fold&Slide hardware GU-923, inward						
Neutral PVC profiles						
Version with dummy-mullion profile						
	Release No.	Level	Released		Scale	Modification
	---	---	---		---	6
	Mod. No.	Ver.	---	---	---	---
	G33134	Draft	23.03.2017	Mj	---	---
Replacement for ---					0-46888-BM-0-EN	
						Sheet
						13/14


Application of drilling jig in case of standard installation of roller track top and bottom




Application of drilling jig in case of alternative installation of roller track
bottom



F&S drilling jig for sash hinge, complete




Installation see 0-44456-DA



A diagram of a wrench. The head of the wrench is on the left, with the number **17** printed on its side. The handle extends to the right and has the number **60** printed on its upper surface. At the end of the handle, there is a circular hole. A leader line points from the number **58** to the handle.

59

Remove chippings from roller track after the drilling.



69

Attention!

For drilling jigs refer to profile-related drawings.

Accessories and drilling jigs

Description

Fold&Slide hardware GU-923, inward

Neutral PVC profiles

Version with dummy-mullion profile

	Release No.	Level	Released		Scale	Modification	Size
	--					6	1
	Mod. No.	Var.	--	--	--		
	G331-134	Drift	23.03.2017	Mj			
	Replacement for --						
Drawing No.						0-46888-BM-0-EN	
						14/14	