

Pos	Benennung				Art.-Nr.	Stück je Schema				
						A	C	D	G	K
1	Laufschuh	vorn	ls		6-32247	1	2	1	2	
2			rs							
2		hinten	ls		6-29555	1	2	1	2	
3	Steuerteil		rs		6-33328	1	2	1	2	
4	Fixierstift	nur bei Schema D			9-39897	--	--	1	--	
5	Schere	vorn	NL 9	ls	6-32204-09	1	--	1	2	
				rs						
			NL 13	ls	6-32204-13					
				rs						
5A	Schere Schema C aktiv	vorn	NL 9	ls	6-34983-09	--	1	--	-	
				rs						
			NL 13	ls	6-34983-13					
				rs						
5B	Schere Schema C passiv	vorn	NL 9	ls	6-32535-09	--	1	--	--	
				rs						
			NL 13	ls	6-32535-13					
				rs						
6	Schere	hinten	NL 9	ls	6-32537-09	1	2	1	2	
				rs						
			NL 13	ls	6-32537-13					
				rs						
7	Abdeckkappe				9-35573	2	4	2	4	
8	Scherengleiter				6-22755	2	4	2	4	
9	Eckumlenkung vorn				6-32539	1	--	1	2	
9A	Eckumlenkung vorn Schema C aktiv				6-34992	--	1	--	--	
9B	Eckumlenkung vorn Schema C passiv				6-32543	--	1	--	--	
10	Eckumlenkung hinten				6-32550	1	2	1	2	
12	Getriebedrehgriff DIRIGENT		ls oder rs		6-24542	1	2	1	2	
13	Müsenmutter				9-30705	2	4	2	4	
14	Senkschraube M5x20 DIN 965				9-13133-20	2	4	2	4	
15	Kupplung	NL 9	Überschlagdicke 14-20		9-30111	1	2	1	2	
		NL 13	Überschlagdicke 15-21,5		9-31015					
		NL 13	Überschlagdicke 21,5-28	auf Wunsch	9-40291					
16	Linsenschraube M5x6 DIN 7985				9-13290-06	2	4	2	4	
17	Abdeckkappe		ls		9-38521	1	2	1	2	
18	Federpuffer		rs		6-29564	1	2	1	2	
19	Halter				9-38522	1	2	1	2	
20	Mittelstück senkrecht	FFH	Länge	TZ	Griffsitz	2	3	2	4	
		820-995	465	-	440					
		996-1120	590	1	440					
		1121-1370	840	1	500					
		1371-1620	1090	1	600					
		1621-1870	1340	2	600					
		1871-2120	1590	2	980					
		2121-2370	1840	2	980					
21	Mittelstück waagrecht	FFB	Länge	TZ		2	4	2	4	
		720-890	730	0						
		891-1100	480	1						
		1101-1350	730	1						
		1351-1600	980	2						
		1601-1850	1230	2						
		FFB	Länge							
		720-1100	800							
25	Stange Ø10	1101-1350	1050		9-23055-10	1	2	1	2	
		1351-1600	1300		9-23055-13					
		1601-1850	1550		9-23055-15					
26	Stützbock	ab FFB 1601			6-29750	1	2	1	2	
27	Abdeckschiene unten P 1602	FFB	Länge			1	2	1	2	
		720-1100	1035		9-38801-10					
		1101-1350	1285		9-38801-13					
		1351-1600	1535		9-38801-15					
		1601-1850	1785		9-38801-18					
28	Laufschiene P 1213			Anwendungsbereich s. Bl. 7	9-30162-99			1		
29	Führungsschiene P 1225				9-30140-99			1		
30	Abdeckschiene P 1226			Längen wie Pos. 29	9-30141			1		
31	Abdeckkappe für Führungsschiene				9-30142			2		
32	Schließplatte Zink				Siehe Tabelle Schließ- und Rastplatten					
34	Rastplatte				Siehe Tabelle Schließ- und Rastplatten					
52	Fehlbediensicherung				K-17060-00-9	1	2	1	2	
53	Stahlschließplatte SE (Stahl)				Siehe Tabelle Schließ- und Rastplatten					
54	Stahlschließplatte SE (Stahl)				Siehe Tabelle Schließ- und Rastplatten					
57	Falzlufbegrenzer				Siehe Tabelle Schließ- und Rastplatten					
58	Flügelzentrierung				9-43223	1	2	1	2	
65	Falzhebelverschluss ZK	FFH	Länge	MV	Griffsitz	--	1	--	--	
		1371-1620	1090	1	495					
		1621-1870	1340	1	703					
66	Falzhebelverschluss ZH	FFH	Länge	MV	Griffsitz	--	1	--	--	
		1371-1620	1090	1	495					
		1621-1870	1340	1	703					
69	Falzhebel ZK				6-25020	--	1	--	--	
69A	Spax. Senkkopfschraube 4x70				9-13246-70	--	2	--	--	
77	Schließplatte Schema C									
77A	Senkschraube M4x10									
78	Pilzkopfschließplatte Schema C									
79	Schließplatte C (Zink) kurz				Siehe Tabelle Schließ- und Rastplatten					
80	Stahlschließplatte C SE (Stahl) kurz				Siehe Tabelle Schließ- und Rastplatten					
81	Stahlschließplatte C SE (Stahl) kurz				Siehe Tabelle Schließ- und Rastplatten					

Tabelle Schließplatten und Rastplatten																								
	Benennung	Fälzung	Art.Nr.	FFB	FFH	Grundsicherheit Stück je Schema				erhöhte Grundsicherheit Stück je Schema				WK 2				FFH	C					
						A	D	G	K	A	D	G	K	A	D	G	K		ohne Pfosten (Stück je Schema)			mit bewegl. Pfosten (Stück je Schema)		
																			Grundsicherheit	erhöhte Grundsicherheit	WK2	Grundsicherheit	erhöhte Grundsicherheit	WK2
32	Schließplatten (Zink)	Eurofalz 18x8	9-42301-18	720-890	820-995	3	6	1	2	für den Aushebeschutz an der hinteren Eckumlenkung	1	2	1371-1620	6	4	für den Aushebeschutz an der hinteren Eckumlenkung	2	10	5	für den Aushebeschutz an der hinteren Eckumlenkung				
		Eurofalz 20x8	9-42301-20	891-1350	820-995	5	10	3	6		1371-1620	10	8	10	13		8							
Eurofalz 24x8	9-42654-00	1351-2100	996-1620	7	14	5	10	1621-1870	12	10	1621-1870	12	10	17	12									
Euronut 7/8x4	9-42620-00	820-995	7	14	5	10	1371-1620	14	12	1371-1620	14	12	18	13										
		996-1620	9	18	7	14	1621-1870	16	14	1621-1870	16	14	21	16										
		1621-2370	11	22	9	18	1871-2370	18	16	1871-2370	18	16	24	19										
53	Stahl schließplatten SE (Stahl)	Eurofalz 18x8	6-32207-18			2	4	4	8	--	--	--	4	6	--	5	10	--						
		Eurofalz 20x8	6-32207-20																					
		Eurofalz 24x8	6-32584-00																					
		Euronut 7/8x4	6-32471-00																					
54	Stahl-schließplatten SE (Stahl)	Eurofalz 18x8	6-33082	720-890	820-995	--	--	--	--	4	8	1371-1620	--	--	--	--	8	13						
					6					12	1621-1870	10					16							
					8					16	1871-2370	12					17							
					6					12	1371-1620	14					20							
					8					16	1621-1870	16					23							
					10					20	1871-2370	16					21							
					8					16	1371-1620	18					24							
					10					20	1621-1870	20					27							
					12					24	1871-2370													
34	Rastplatte	Eurofalz 18x8	9-43636-18	--	3	6	3	6	6	6	6													
		Eurofalz 20x8	9-43636-20																					
		Eurofalz 24x8	9-43636-24																					
		Euronut 7/8x4	9-30430-00																					
57	Falzlufbegrenzer	9-43219		2	4	4	8	4	8	--														
77	Schließplatte Schema C	9-31960	--	auf Wunsch			auf Wunsch			Standard			1371-1620	2	1	--	--	--	--					
										1621-1870	3	2												
										1871-2370	4	3												
77A	Senkschraube M6x10	9-13281-10	--	--			--			1371-1620	2		--	--	--	--								
										1621-1870	3													
										1871-2370	4													
78	Pilzkopfschließplatte Schema C	9-39189	--	--			--			1371-1620	3	1	2	--	--	--								
										1621-1870	4													
										1871-2370	5													
79	Schließplatte C (Zink) kurz	Eurofalz 18x8	9-46000-01	--	--	--	--	2	--	--	--	(2 wenn Maß Z < 33)	--	--										
		Eurofalz 20x8	9-46000-02																					
		Eurofalz 24x8	9-46000-03																					
		Euronut 7/8x4	9-46000-04																					
80	Stahl-schließplatte C SE (Stahl) kurz	Eurofalz 18x8	9-46000-05	--	--	--	--	2	--	--	--	(2 wenn Maß Z < 33)	--	--										
		Eurofalz 20x8	9-46000-06																					
		Eurofalz 24x8	9-46000-07																					
		Euronut 7/8x4	9-46000-08																					
81	Stahl-schließplatte C SE (Stahl) kurz	Eurofalz 18x8	9-46000-09	--	--	--	--	2	--	--	2	--	--	--										
		Eurofalz 20x8	6-35349-00																					
		Eurofalz 24x8	9-46000-07																					
		Euronut 7/8x4	9-46000-10																					


Der gesamte Beschlag wird in Kippstellung angeschlagen.

1. Eckwinkel unten (Pos. 9 u. 10) und Scherenwinkel oben (Pos. 5 u. 6) montieren und in Kippstellung - Montagestellung bringen.



2. Mittelstück senkrecht (Pos. 20) bzw. abschließbares Gerliebe (Pos. 4), und Mittelstück waagrecht (Pos. 21) kürzen, in Eckwinkel bzw. Scherenwinkel einhängen, und festschrauben. (Montagestellung ist durch Blockierstift vorgegeben. Schließzapfenmitte liegt auf der Stulpmarkierung).
- Hinweis: Beim kürzen der Mittelstücke waagrecht Gr.01 muss die Seite mit langer Verzahnung bündig mit dem Stulp sein.

3. Verbindungslaschen bis zum Anschlag über den Stulp schieben und verschrauben



4. Kupplung (Pos. 15) montieren.
5. Getriebe-Drehgriff (Pos. 12) montieren.
wobei Mitnehmer in Kupplung eingreifen muss.
Alternativ: Drehgriff (Pos. 35) montieren.
6. Laufschiub (Pos. 1 u. 2) vorn und hinten befestigen.
7. Halter (Pos. 19) auf Flügelmitte montieren.
8. Stange (Pos. 25) kürzen und in hinteren Laufschiub einschieben.
Hinteren Laufschiub fest anschrauben, in den vorderen Laufschiub einschieben.
Laufschiube in Schussstellung bringen und anschrauben am vorderen Laufschiub fest anziehen, Drehmoment 10 - 12 Nm.

9. Schließplatten und Rastplatten setzen. Einlegelehren wie in der Zeichnung dargestellt, verwenden.

10. Führungsschiene P 1225 (Pos. 29) und Abdeckschiene P 1226 (Pos. 30) kürzen. Führungsschiene montieren, Scherengleiter (Pos. 8) einführen und Abdeckkappen (Pos. 31) anbringen.
11. Laufschiene unten P 1213 (Pos. 28) kürzen und montieren.
12. Steuerleiste (Pos. 3) auf die Laufschiene schieben und Schrauben mit Schlüssel SW4 fest anziehen. Drehmoment 10 - 12 Nm. Bei Elementen ohne Prosten (Schema D), Bohrlöcher 6-30447 verwenden.

13. Beschlag in Kippstellung bringen (Drehgriff steht waagrecht).

14. Flügel schräg auf die Laufschiene stellen. Scherenbolzen ganz in Gleiter einstecken und mit Schlüssel SW4 verriegeln (siehe Blatt 3).
Um sichere Verriegelung zu prüfen, kräftig am Scherenarm ziehen.

15. Parallelstellung in Schieberichtung nicht vorhanden:
Klemmschrauben für Stange am vorderen Laufschuh lösen.
Flügel parallel ausrichten, Schrauben wieder fest anziehen.

16. Parallelstellung senkrecht nicht vorhanden:
Sperrschieber für Höheneinstellung am vorderen und hinteren Laufschuh nach vorn herausziehen, mit Schlüssel SW 4 Flügel senkrecht ausrichten.
Sperrschieber wieder hineindrücken.
17. Flügel läuft nicht mittig in den Rahmen:
Klemmschrauben am Steuerteil lösen, Steuerteil entsprechend verschieben.
Schrauben wieder fest anziehen.
18. Flügelzentrierung (Pos. 58) mittig montieren.
Bei Bedarf durch Verschieben ausrichten.
19. Federpuffer (Pos. 18) entsprechend der gewünschten Öffnungsweite in Laufschiene einschwenken und mit Schlüssel SW 4 fest anziehen.
20. Abdeckschiene p 1226 (Pos. 30) auf Führungsschiene P 1225 (Pos. 29) klinken.
21. Abdeckschiene P 1602 (Pos. 27) kürzen und zwischen Laufwagen klinken.
22. Abdeckkappen (Pos. 17) von oben einschieben bis diese klinken.
23. Laufschiene P 1213 (Pos. 28) muß auf ganzer Länge unterfüttert und mit dem Rahmen verschraubt werden.

Die angegebenen Befestigungsschrauben sind eine auf unserer Erfahrung beruhende Empfehlung.

Die Verantwortung für eine ausreichende Befestigung der Beschlagteile liegt beim Hersteller von Fenstern und Fenstertüren.

Beschlagteile im Auslieferungszustand dargestellt.

Beschlagübersicht

Description						
Parallelschiebe-Kippbeschlag GU-966/200 mZ TZ Holz Eurofalz 18x8, 20x8 und 24x8 und Euronut 7/8x4 —						
	Release No.	Level	Released		Scale	Modification
	--	Ver.	--	--	%	4
	Mod. No. 626808	Draft	02.02.09	Mo	Drawing No.	
	Replacement for --				0-45253-BK-0-0	

* Bei Eurofalz 24x8 ist NL 13 erforderlich.

Flügelstreckhöhe FFH

118

Technical drawing of a door assembly showing a cross-section and a perspective view. The cross-section shows the door frame, door leaf, and various components like the hinge, latch, and handle. Dimensions are given in mm. Labels include:

- Über-schlag-dicke
- Unterfütterung der Laufschiene bis Rahmenaußenkante
- Länge der Laufschiene bis Flügelaußenkante
- Abdeckschiene P 1602
- Flügelfalzbreite FFB
- Rahmeninnenbreite RIB
- Rahmenaußenbreite RAB
- Montage Federpuffer
- Ende Laufschiene

Aussperrung

Schiebeflügel/Drehflügel
mit festem Mittelpfoster

Einbau Drehflügelbeschlag
nach WZ 0-44324 (Grundsicherheit)
WZ 0-44917 (WK)

Einlegelehren für Schließplatten bei Eurofalz 18x8, 20x8 und 24x8	
FFH 820-1120	6-32988-04
FFH 1121-1870	6-32988-03
FFH 1871-2370	6-32988-02
FFB 890-2100	6-32988-01
Einlegelehre für Rastplatten	6-29945-11

Einlegelehren für Schließplatten bei Euronut 7/8x4	
FFH 820-1120	6-32988-04
FFH 1121-1870	6-32988-03
FFH 1871-2370	6-32988-02
FFB 890-2100	6-32988-01
Einlegelehre für Rastplatten	6-29945-01

Schiebeflügel/Festverglasung


Release No. --	Level Ver.	Released --		Scale %	Modification 4	Size 1
Mod. No. G26808	Draft	02.02.09	Mo		Drawing No. 0-45253-BK-0-0	Sheet 3
Replacement for --						






Description

Parallelschiebe-Kippbeschlag GU-966/200 mZ TZ



Holz Eurofalz 18x8, 20x8 und 24x8 und Euronut 7/8x4

—




	Release No.	Level		Released	Scale	Modification	Size
	--	Ver.		--	%	4	Sheet
	Mod. No.	Draft		Mo			
	GZ6808	02.02.2009				Drowning No.	
	Replacement for --					0-45253-BK-00	4/7



Passivflügel mit beweglichem Pfosten



Description						
Parallelschiebe-Kippbeschlag GU-966/200 mZ TZ Holz Eurofalz 18x8, 20x8 und 24x8 und Euronut 7/8x4						
GU	Release No.	Level	Released	Scale		Size
	Mod. No.	Ver.	--	%		1
	Draft	02.02.2009	Mo	Drawing No.		Sheet
Replacement for --				O-45253-BK-0-0		5/7




Montagehinweis zu Schema D

Bohrlehre mit den Bohrbuchsen auf die Laufschiene stellen, am Steuerteil anlegen und mit den Stiften gegen die Laufschiene abstützen. Anschließend die entsprechende Bohrung (LS oder RS) anbringen.

Fixierstift in die Bohrung eindrücken. Der Stift dient bei Schema D als Anschlag für verschiebbares Steuerteil.

Achtung: PSK Puffer (Pos. 44 muss wie das Steuerteil (Pos. 3) gelöst und verschoben werden.

Schema D



Schiebflügel/Drehflügel mit loseem Mittelpfosten

Description


Parallelschiebe-Kippbeschlag GU-966/200 mZ TZ
Holz Eurofalz 18x8, 20x8 und 24x8 und Euronut 7/8x4

	Release No.	Level	Released		Scale	Modification	Size
	--				1:1	4	1
	Mod. No. GZ6808	Ver.	--	--			
	Draft	02.02.09	Mo				
Replacement for --					0-45253-BK-0-0		Sheet 6/7

Item	Description			Article no.	Qty. per scheme					
					A	C	D	G	K	
1	Runner	front	lh	6-32247	1	2	1	2		
2		rear	lh	6-29555	1	2	1	2		
3	Control part		rh	6-33328	1	2	1	2		
4	Fixing pin	only with scheme D		9-39897	--	--	1	--		
5	Stay arm	front	GR 9 lh	6-32204-09	1	--	1	2		
			GR 13 rh	6-32204-13						
5A	Stay arm scheme C active sash	front	GR 9 lh	6-34983-09	--	1	--	-		
			GR 13 rh	6-34983-13						
			GR 9 lh	6-32535-09						
5B	Stay arm scheme C passive sash	front	GR 13 rh	6-32535-13	--	1	--	--		
			GR 9 lh	6-32537-09						
6	Stay arm	rear	GR 13 rh	6-32537-13	1	2	1	2		
			GR 9 lh	6-32537-13						
7	Cover			9-35573	2	4	2	4		
8	Stay arm glider			6-22755	2	4	2	4		
9	Corner transmission front			6-32539	1	--	1	2		
9A	Front corner transmission scheme C, active sash			6-34992	--	1	--	--		
9B	Front corner transmission scheme C, passive sash			6-32543	--	1	--	--		
10	Corner transmission rear			6-32550	1	2	1	2		
12	Geared handle DIRIGENT		lh or rh	6-24542	1	2	1	2		
13	Threaded sleeve			9-30705	2	4	2	4		
14	Countersunk screw M5x20 DIN 965			9-13133-20	2	4	2	4		
15	Coupling piece	GR 9	Overlap thickness 14-20	9-30111	1	2	1	2		
		GR 13	Overlap thickness 15-21.5	9-31015						
		GR 13	Overlap thickness 21.5-28 optional	9-40291						
16	Dome headed screw M5x6 DIN 7985			9-13290-06	2	4	2	4		
17	Plug		lh	9-38521	1	2	1	2		
18	Spring-loaded buffer		rh	6-29564	1	2	1	2		
19	Support			9-38522	1	2	1	2		
20	Centre piece, vertical	SRH	Length	TZ	Handle height	2	3	2	4	
		820-995	465	-	440					6-32304-01
		996-1120	590	1	440					6-32304-02
		1121-1370	840	1	500					6-32304-03
		1371-1620	1090	1	600					6-32304-04
		1621-1870	1340	2	600					6-32304-05
		1871-2120	1590	2	980					6-32304-06
21	Centre piece, horizontal	SRW	Length	TZ		2	4	2	4	
		720-890	730	0						6-32307-02
		891-1100	480	1						6-32307-01
		1101-1350	730	1						6-32307-02
		1351-1600	980	2						6-32307-03
		1601-1850	1230	2						6-32307-04
		25	Rod Ø10	SRW	Length					
720-1100	800					9-23055-08				
1101-1350	1050					9-23055-10				
1351-1600	1300					9-23055-13				
1601-1850	1550					9-23055-15				
26	Guide	from SRW 1601			6-29750	1	2	1	2	
27	Cover rail P 1602, bottom	SRW	Length			1	2	1	2	
		720-1100	1035							9-38801-10
		1101-1350	1285							9-38801-13
		1351-1600	1535							9-38801-15
		1601-1850	1785							9-38801-18
28	Running rail P 1213				9-30162-99		1			
29	Gliding rail P 1225			Application range see sheet 7	9-30140-99		1			
30	Cover rail P 1226			Same lengths as item 29	9-30141		1			
31	Plug f. gliding rail				9-30142		2			
32	Locking plate, zinc					See table of locking and positioning plates				
34	Positioning plate					See table of locking and positioning plates				
52	Wrong operation safety device				K-17060-00-9	1	2	1	2	
53	Locking plate SE, steel					See table of locking and positioning plates				
54	Locking plate SE, steel					See table of locking and positioning plates				
57	Rebate clearance restrictor					See table of locking and positioning plates				
58	Sash centering device				9-43223	1	2	1	2	
65	Rebate shoot bolt ZK	SRH	Length	ML	Handle height	6-33018-04	--	1	--	
		1371-1620	1090	1	495	6-33018-55				
		1621-1870	1340	1	703	6-33018-55				
66	Rebate shoot bolt ZH	SRH	Length	ML	Handle height	6-33017-04	--	1	--	
		1371-1620	1090	1	495	6-33017-55				
		1621-1870	1340	1	703	6-33017-55				
69	Rebate lever ZK				6-25020	--	1	--	--	
69A	Spax countersunk screw 4x70				9-13246-70	--	2	--	--	
77	Locking plate scheme C									
77A	Countersunk screw M4x10									
78	Mushroom pin locking plate scheme C									
79	Locking plate scheme C (zinc), short					See table of locking and positioning plates				
80	Locking plate SE scheme C (steel), short									
81	Locking plate SE scheme C (steel), short									

Table of locking and positioning plates																									
	Description	Rebating	Article no.	SRW	SRH	Basic security Qty. per scheme			Enhanced basic security Qty. per scheme				WK 2			SRH	C								
						A	D	G	K	A	D	G	K	A	D		G	K	without false mullion (Qty. per scheme)			with false mullion (Qty. per scheme)			
																			Basic security	Enhanced basic security	WK2	Basic security	Enhanced basic security	WK2	
32	Locking plate, zinc	Euro rebate 18x8	9-42301-18	720-890	820-995	3	6	1	2	for anti-lift security device on rear corner transmission	1	2	1371-1620	6	4	for anti-lift security device on rear corner transmission	2	10	5	for anti-lift security device on rear corner transmission	2				
					996-1620	5	10	3	6				1621-1870	8	6			13	8						
					1621-2370	7	14	5	10				1871-2370	10	8			16	11						
		Euro rebate 20x8	9-42301-20	891-1350	820-995	5	10	3	6				1371-1620	10	8			14	9						
					996-1620	7	14	5	10				1621-1870	12	10			17	12						
					1621-2370	9	18	7	14				1871-2370	14	12			20	15						
		Euro rebate 24x8	9-42654-00		820-995	7	14	5	10				1371-1620	14	12			18	13						
53	Locking plate SE, steel	Euro groove 7/8x4	9-42620-00	1351-2100	996-1620	9	18	7	14			1621-1870	16	14		21	16								
					1621-2370	11	22	9	18			1871-2370	18	16		24	19								
		Euro rebate 18x8	6-32207-18																						
54	Locking plate SE, steel	Euro rebate 20x8	6-32207-20																						
		Euro rebate 24x8	6-32584-00																						
		Euro groove 7/8x4	6-32471-00																						
77	Countersunk screw M4x10	Euro rebate 18x8	6-33082	720-890	820-995																				
					996-1620																				
					1621-2370																				
		Euro rebate 20x8	6-33585	891-1350	820-995	--	--	--	--																
					996-1620																				
					1621-2370																				
		Euro rebate 24x8	6-32584		820-995																				
78	Mushroom pin locking plate scheme C	Euro groove 7/8x4	6-33082-07	1351-2100	996-1620																				
					1621-2370																				
79	Locking plate scheme C (zinc), short	Euro rebate 18x8	9-43636-18	--	3	6	3	6	3	6															
		Euro rebate 20x8	9-43636-20																						
		Euro rebate 24x8	9-43636-24																						
		Euro groove 7/8x4	9-30430-00																						
80	Locking plate SE scheme C (steel), short	Euro rebate 18x8	9-46000-01																						
		Euro rebate 20x8	9-46000-02																						
		Euro rebate 24x8	9-46000-03																						
		Euro groove 7/8x4	9-46000-04																						
81	Locking plate SE scheme C (steel), short	Euro rebate 18x8	9-46000-05																						
		Euro rebate 20x8	9-46000-06																						
		Euro rebate 24x8	9-46000-07																						
		Euro groove 7/8x4	9-46000-08																						
82	Locking plate SE scheme C (steel), short	Euro rebate 18x8	9-46000-09																						
		Euro rebate 20x8	9-35349-00																						
		Euro rebate 24x8	9-46000-07																						
		Euro groove 7/8x4	9-46000-10																						

Length of gliding rail P 1225 and cover rail P 1226 up to outer edge of sash, each




Monting instructions

Drilling and cutting according to specified dimensions, preferably by means of appropriate jigs. Peripheral rebate clearance 12 mm.

Mounting on sash


All fitting components are mounted in tilt position.

1. Mount corner transmissions (items 9,10) at bottom and stay arms (items 5, 6) at top and put in tilt position, each.



2. Cut to length vertical centre pieces (item 20), lockable gear (item 41, if used), and horizontal centre piece (item 21); engage them in corner transmissions and angle stay arms, each, and fasten with screws. (Correct mounting position predefined by arresting pin; centre of mushroom pin must be aligned with marking notches).
Note: when cutting the horizontal centre pieces size 01, ensure that the long toothed section is flush with the gear end.

3. Slide connecting plates over centre pieces/gear until stop and fasten with screws.



4. Mount coupling (item 15).
5. Mount geared handle (item 12); ensure that carrier piece engages in the coupling.
Alternative: mount handle item 35
6. Fasten front (item 1) and rear runner (item 2).
7. Fasten support (item 19) at centre of sash.
8. Cut connecting rod (item 25) and insert into rear runner. Tighten screws and insert rod into front runner. Put runners to closed position and firmly tighten screw on front runner. Tightening torque 10 - 12 Nm.

Mounting on frame

9. Insert locking plates and positioning plates using the appropriate jigs as shown in drawing.
10. Cut gliding rail P 1225 (item 29) and cover rail P 1226 (item 30) to length. Mount gliding rail, insert stay arm glider (item 8) and attach covers (item 31).
11. Cut running rail P 1213 (item 28) to length and mount.
12. Slide control part (item 3) onto running rail and tighten screws firmly using an Allen key size 4. Tightening torque 10 - 12 Nm.
For elements without mullion (scheme D) use drilling jig 6-30447.

Installing the sliding sash

13. Put fittings in tilt position (lever handle in horizontal position).
14. Place sash on running rail in inclined position. Insert stay arm pin fully into glider (item 8) and tighten with Allen key size 4 (see sheet 3). Verify fastening is secure by pulling on stay arm vigorously.

Verifying the correct sash position

15. If sash is not parallel in horizontal direction:
Loosen clamping screws for connecting rod on front runner, align sash in parallel, retighten screws firmly.
16. Sash is not parallel in vertical direction:
Pull out catches for height adjustment on front and rear runner. Align the sash vertically using a 4mm Allen key. Push catches back in again.
17. If sash does not run centrally into frame:
Loosen clamping screws on control part to adjust it as required, retighten screws firmly.
18. Mount sash centering device (item 58) centrally.
Align by sliding, if necessary.
19. Mount spring-loaded buffer (item 18) onto running rail according to the opening width desired, then tighten with 4mm Allen key.
20. Clip cover rail P 1226 (item 30) onto gliding rail P 1225 (item 29).
21. Cut cover rail P 1602 (item 27) and clip it between runners.
22. Insert covers (item 17) from above until they snap in.
23. Running rail P 1213 (item 28) must be supported over its total length and fixed to the frame with screws.

The fastening screws specified are only a recommendation based on our experience.

The responsibility for the appropriate fastening of fitting components rests with the window/ window door fabricator.

Fitting components illustrated in ex factory state.

Overview of fitting components






Description

Parallel Slide and Tilt Fittings GU-966/200 mZ TZ (automatic locking pin)
Timber - Euro groove 18x8, 20x8, 24x8 and Euro rebate 7/8x4



GU

Release No.	Level	Released		Scale	Modification	Sheet
Mod. No. G26908	Ver.	--	--	%	4	1
	Draft	02.02.09	Mo	Drawing No. 0-45253-BK-0-GB		Sheet
Replacement for --						2/7


1.15




Passive sash
with false mullion



Scheme C / Detailed sections






2 sliding sashes / fixed glazing
without mullion or
2 sliding sashes / fixed glazing
with false mullion



2 sliding sashes / 2 side hung
sash without mullion or
2 sliding sashes / 2 side hung
sash with false mullion

Description							
Parallel Slide and Tilt Fittings GU-966/200 mZ TZ (automatic locking pin) Timber - Euro groove 18x8, 20x8, 24x8 and Euro rebate 7/8x4							
GU	Release No.	Level	Released	Scale	Modification	Size	
	Mod. No. GZ6808	Ver.	--	--	4	1	
	Draft	02.02.2009	Me	%	Drawing No.	Sheet	
Replacement for --				0-45253-BK-0-GB			5/7



Mounting the fixing pin for Scheme D


Place drilling jig with drilling bushes on running rail, align with control part and support with pins against the rail. Then drill the corresponding hole (lh or rh).

Press fixing pin into bore hole. With scheme D, the pin serves as stop for the shiftable control part.

Attention:

Buffer (item 44) must be loosened and shifted in the same way as the control part (item 3).

Scheme D












Sliding sash/side hung sash with false mullion

Description							
Parallel Slide and Tilt Fittings GU-966/200 mZ TZ (automatic locking pin) Timber - Euro groove 18x8, 20x8, 24x8 and Euro rebate 7/8x4							
GU	Release No.	Level	Released		Scale	Modification	
	Mod. No. G26808	Ver.	--	--		4	1
		Draft	02.02.09	Mo	Drawing No.		Sheet
	Replacement for --					0-45253-BK-0-GB	6/7

Gliding rail P 1225

8.2

26.2



Drilling and milling jigs

Description

Parallel Slide and Tilt Fittings GU-966/200 mZ TZ (automatic locking pin)
Timber - Euro groove 18x8, 20x8, 24x8 and Euro rebate 78x4

	Release No.	Level	Released	Scale	Modification	Size
	Mod. No.	Ver.	--			
	626808	Draft	02.02.09			
	Replacement for --		Mo			
					Drawing No.	Sheet
					0-45253-BK-0-CB	7/7